Programming Remote to TV

URC 2025

Linking the STB to the Remote

- 1. Press and release the **STB** button.
- 2. Press and hold **Setup + (A or B)** at the same time until STB LED on the remote blinks twice.
 - A for a Cisco box
 - **B** for a Motorola or Arris box

Programming Remote to Operate your TV

- Turn on the TV. You will need to do this with either the branded TV remote or a physical button on the TV.
- 2. Press and release the **TV** button.
- Press and hold the **Setup** button until the **TV** button on the remote blinks twice.
- 4. Press and release the TV button. It will stay lit.
- Press and hold the **OK/Select** button, or the number related to your TV brand, until your physical TV turns off.

Insignia/Dynex	1
LG/Zenith	2
Mitsubishi	3
Panasonic	4
Phillips/Magnavox	5
Samsung	6
Sharp	7
Sony	8
Toshiba	9
Vizio	0

6. Press the **STB** button last to control the STB.



844.354.4111

nuvera.net